

## XLR to 5 Pin GX16

Output Adapter for the Cycle Satiator Charger with GX16 connector for EUC batteries, and a TRS Cable for communications.



Grin Technologies 1290 Odlum Dr. Vancouver, BC

info@ebikes.ca www.ebikes.ca

## Part #: W-XLR GX16 5F

- High current (15A) Neutrik XLR connector
- TRS jack for connecting Satiator to PC using TTL-USB cable
- 5 pin female GX16 connector
- Batteries with GX connectors often require v1.039 Satiator firmware, available at https://ebikes.ca/productinfo/grin-products/cycle-satiator.html#Downloads

## **Specifications**

Cable Length 16cm

Input Connector XI R Neutrik NC3FXX

Pin 1 = DC +, Pin 2 = DC -, Pin 3 = Signal

**Output Connector** 

GX16-5F Pin 1 = DC +, Pin 5 = DC -

TRS Jack Communication

Tip=Rx, Ring=TX, Sleeve=Gnd

For more information, visit www.ebikes.ca



www.ebikes.ca

Advancing the world of ebike parts and accessories